

**Lista de Números de Série Sob Risco**

<b>Série</b>	<b>Descrição</b>	<b>Manga de Fluxo</b>
E02052	PRISMAFLO IIS	E22078
E02679	PRISMAFLO IIS	E22813
E02682	PRISMAFLO IIS	E22816
E02683	PRISMAFLO IIS	E22817
E02684	PRISMAFLO IIS	E22818
E02821	PRISMAFLO IIS	E22928
E02822	PRISMAFLO IIS	E22929
E02823	PRISMAFLO IIS	E22930
E02843	PRISMAFLO IIS	E22950
E02857	PRISMAFLO IIS	E22964
E02858	PRISMAFLO IIS	E22965
E02859	PRISMAFLO IIS	E22966
E02860	PRISMAFLO IIS	E22967
E02889	PRISMAFLO IIS	E22981
E02890	PRISMAFLO IIS	E22986
E02892	PRISMAFLO IIS	E22998
E02894	PRISMAFLO IIS	E23000
E02895	PRISMAFLO IIS	E23001
E02897	PRISMAFLO IIS	E23003
E03137	PRISMAFLO II S 230 VAC	E232500
E03138	PRISMAFLO II S 230 VAC	E23292
E03139	PRISMAFLO II S 230 VAC	E23293
E03140	PRISMAFLO II S 230 VAC	E23294
E03141	PRISMAFLO II S 230 VAC	E23295
E03142	PRISMAFLO II S 230 VAC	E23296
E03143	PRISMAFLO II S 230 VAC	E23297
E03144	PRISMAFLO II S 230 VAC	E23298
E03145	PRISMAFLO II S 230 VAC	E23299
E03146	PRISMAFLO II S 230 VAC	E23300
E03147	PRISMAFLO II S 230 VAC	E23301
E03148	PRISMAFLO II S 230 VAC	E23302
E03149	PRISMAFLO II S 230 VAC	E23303
E03150	PRISMAFLO II S 230 VAC	E23304
E03151	PRISMAFLO II S 230 VAC	E23305
E03154	PRISMAFLO II S 230 VAC	E23308
E03155	PRISMAFLO II S 230 VAC	E23343
E03156	PRISMAFLO II S 230 VAC	E23344
E03157	PRISMAFLO II S 230 VAC	E23345
E03158	PRISMAFLO II S 230 VAC	E23346
E03247	PRISMAFLO II S 230 VAC	E23426
E03248	PRISMAFLO II S 230 VAC	E23427
E03249	PRISMAFLO II S 230 VAC	E23428
E03250	PRISMAFLO II S 230 VAC	E23429
E03251	PRISMAFLO II S 230 VAC	E23430
E03257	PRISMAFLO II S 230 VAC	E23436
E03265	PRISMAFLO II S 230 VAC	E23464
E03273	PRISMAFLO II S 230 VAC	E23472
E03252	PRISMAFLO II S 230 VAC	E23431
E03253	PRISMAFLO II S 230 VAC	E23432
E03254	PRISMAFLO II S 230 VAC	E23433
E03255	PRISMAFLO II S 230VAC	E23434
E03256	PRISMAFLO II S 230 VAC	E23435
E03258	PRISMAFLO II S 230 VAC	E23437
E03259	PRISMAFLO II S 230 VAC	E23438

<b>Série</b>	<b>Descrição</b>	<b>Manga de Fluxo</b>
E03260	PRISMAFLO II S 230 VAC	E23439
E03261	PRISMAFLO II S 230 VAC	E23440
E03262	PRISMAFLO II S 230 VAC	E23441
E03263	PRISMAFLO II S 230 VAC	E23442
E03264	PRISMAFLO II S 230 VAC	E23463
E03266	PRISMAFLO II S 230 VAC	E23465
E03267	PRISMAFLO II S 230 VAC	E23466
E03268	PRISMAFLO II S 230 VAC	E23467
E03269	PRISMAFLO II S 230 VAC	E23468
E03270	PRISMAFLO II S 230 VAC	E23469
E03271	PRISMAFLO II S 230 VAC	E23470
E03272	PRISMAFLO II S 230 VAC	E23471
E03274	PRISMAFLO II S 230 VAC	E23473
E03275	PRISMAFLO II S 230 VAC	E23474
E03276	PRISMAFLO II S 230 VAC	E23475
E03277	PRISMAFLO II S 230 VAC	E23476